

Płaskowniki walcowane według DIN 1017

wymiar			S355J2G3 / S355JO 18G2A	C45 gat. 45	C60 gat. 60	16/ 20MnCrS5 16/ 20HG	42CrMo4S4V 40HM ulepsz.
16	x	6	●				
		10	●				
20	x	4	●	●			
		5	●	●			
		6	●	●			
		8	●				
		10	●	●		●	
		12	●	●		●	
		15	●	●		●	
25	x	4	●	●			
		5	●	●			
		6	●	●			
		8	●	●		●	
		10	●	●		●	
		12	●	●		●	●
		15	●	●		●	●
		20	●	●		●	●
30	x	3	●	●			
		4	●	●			
		5	●	●			
		6	●	●			
		10	●	●		●	●
		12	●	●		●	●
		15	●	●		●	
		20	●	●		●	●
		25	●	●		●	●
35	x	4	●	●			
		5	●	●			
		6	●	●			
		8	●	●			
		10	●	●		●	
		12	●	●			
		15	●	●			
		20	●	●		●	
		25	●	●		●	
		30	●	●			●
40	x	3	●				
		4	●	●			
		5	●	●			
		6	●	●	●		
		8	●	●			
		10	●	●		●	
		12	●	●		●	●
		13	●				
		15	●	●		●	
		16	●				
		20	●	●	●	●	●
		25	●	●	●	●	●
		30	●	●	●	●	●
		35	●	●			

KONTAKT
PRIMO-STAL Sp z o.o.
ul. Słowackiego 6

59-550 Wojcieszów
tel. +48 75 75 12 665
e-mail. biuro@primo-stal.com

45	x	4	●	●			
		5	●	●			
		6	●	●			
		8	●	●			
		10	●	●			
		12	●	●			
		15	●	●		●	
		20	●	●		●	
		25	●	●		●	
		30	●	●		●	●
		35	●	●			
		40	●	●			
50	x	4	●	●			
		5	●	●			
		6	●	●			
		7	●	●			
		8	●	●			
		10	●	●	●	●	●
		12	●	●	●	●	●
		13	●				
		15	●	●	●	●	●
		20	●	●	●	●	●
		25	●	●	●	●	●
		30	●	●	●	●	●
		35	●	●		●	●
		40	●	●	●	●	●
		45	●				
55	x	5	●				
		6	●	●			
		8	●	●			
		10	●	●			
		12	●	●			
		15	●	●			
		20	●	●		●	
		25	●			●	
		30	●	●		●	●
		35	●	●			
		40	●	●			
		45	●				
60	x	5	●	●			
		6	●	●	●		
		8	●	●		●	
		10	●	●	●	●	
		12	●	●	●	●	●
		15	●	●	●	●	●
		20	●	●	●	●	●
		25	●	●	●	●	●
		30	●	●	●	●	●
		35	●	●		●	●
		40	●	●	●	●	●
		45	●	●			
		50	●	●	●	●	●
65	x	5	●				
		6	●	●			
		8	●	●			
		10	●	●			

65	x	12	●	●			
		15	●	●			
		20	●	●			
		25	●	●			
		30	●	●		●	●
		35	●	●			
		40	●	●			
		45	●				
		50	●	●			
70	x	5	●	●			
		6	●	●			
		8	●	●			
		10	●	●		●	●
		12	●	●	●	●	●
		15	●	●	●	●	●
		16	●				
		20	●	●	●	●	●
		25	●	●	●	●	●
		30	●	●	●	●	●
		35	●	●		●	●
		40	●	●	●	●	●
		45	●	●			
		50	●	●	●	●	●
		60	●	●		●	●
75	x	5	●				
		6	●	●			
		8	●	●			
		10	●	●			
		12	●	●			
		15	●	●			
		20	●	●			
		25	●	●			
		30	●				
		35	●	●			
		40	●	●			
		45	●				
		50	●	●			
80	x	5	●	●			
		6	●	●			
		8	●	●			
		10	●	●	●	●	●
		12	●	●	●	●	●
		15	●	●	●	●	●
		20	●	●	●	●	●
		25	●	●	●	●	●
		30	●	●	●	●	●
		35	●	●		●	●
		40	●	●	●	●	●
		45	●	●			
		50	●	●	●	●	●
		60	●	●	●	●	●
		70	●	●		●	●
90	x	5	●	●			
		6	●	●			
		8	●	●			
		10	●	●			

90	x	12	●	●	●	●	●
		15	●	●		●	●
		20	●	●		●	●
		25	●	●		●	●
		30	●	●		●	●
		35	●	●		●	
		40	●	●		●	●
		45	●				
		50	●	●		●	●
		60	●	●	●	●	●
		70	●	●		●	●
		80	●	●			
100	x	5	●	●			
		6	●	●			
		8	●	●			
		10	●	●	●	●	●
		12	●	●		●	
		15	●	●	●	●	●
		20	●	●	●	●	●
		25	●	●	●	●	●
		30	●	●	●	●	●
		35	●	●		●	●
		40	●	●	●	●	●
		45	●	●			
		50	●	●	●	●	●
		60	●	●	●	●	●
		65	●	●			
		70	●	●		●	●
		75	●				
		80	●	●		●	●
		90	●	●			
110	x	5		●			
		6	●	●			
		8	●	●			
		10	●	●		●	
		12	●	●			
		15	●	●		●	
		16	●				
		20	●	●		●	●
		25	●	●		●	●
110	x	30	●	●		●	●
		35	●	●			
		40	●	●		●	●
		45	●	●			
		50	●	●		●	●
		60	●	●		●	●
		70	●	●		●	●
		80	●	●		●	●
		90	●	●		●	●
		100	●	●			
120	x	5	●				
		6	●	●			
		8	●	●			
		10	●	●		●	
		12	●	●		●	
		15	●	●		●	

KONTAKT
PRIMO-STAL Sp z o.o.
ul. Słowackiego 6

59-550 Wojcieszów
tel. +48 75 75 12 665
e-mail. biuro@primo-stal.com

120	x	20	●	●	●	●	●
		25	●	●	●	●	●
		30	●	●	●	●	●
		35	●	●		●	●
		40	●	●	●	●	●
		45	●				
		50	●	●	●	●	●
		60	●	●	●	●	●
		70	●	●		●	●
		80	●	●		●	●
		90	●	●		●	
		100	●	●		●	●
125	x	40	●				
130	x	5	●				
		6	●	●			
		8	●	●			
		10	●	●		●	
		12	●	●			
		15	●	●	●	●	
		20	●	●	●	●	●
		25	●	●		●	●
		30	●	●		●	●
		35	●	●		●	
		40	●	●		●	●
		50	●	●		●	●
		60	●	●		●	●
		70	●	●		●	
		80	●	●		●	●
		90	●	●		●	
		100	●	●		●	
		110	●	●		●	
		120		●			
140	x	5	●			●	
		6	●	●			
		8	●	●			
		10	●	●			
		12	●	●			
		15	●	●	●	●	
		20	●	●	●	●	●
		25	●	●		●	●
		30	●	●	●	●	●
		35	●	●		●	
		40	●	●	●	●	●
		50	●	●		●	●
		60	●	●		●	●
		70	●	●		●	●
		80	●	●		●	●
		90	●	●		●	
		100	●	●		●	
		110	●	●			
		120	●	●		●	
150	x	5	●				
		6	●	●			
		8	●	●			
		10	●	●		●	
		12	●	●			

150	x	15	●	●		●	
		20	●	●	●	●	●
		25	●	●	●	●	●
		30	●	●	●	●	●
		35	●	●		●	
		40	●	●	●	●	●
		45	●				
		50	●	●	●	●	●
		60	●	●	●	●	●
		70	●	●		●	●
		80	●	●		●	●
		90	●	●			
		100	●	●		●	●
		120		●		●	

Płaskowniki szerokie według DIN 59200

wymiar			S355J2G3 / S355JO 18G2A	C45 gat. 45	C60 gat. 60	16/ 20MnCrS5 16/ 20HG	42CrMo4S4V 40HM uleps.
160	x	6	●				
		8	●				
		10	●	●		●	
		12	●	●			
		15	●	●		●	
		20	●	●	●	●	●
		25	●	●		●	●
		30	●	●		●	●
		35	●	●			
		40	●	●		●	●
		50	●	●		●	●
		60	●	●		●	
		70	●	●		●	
		80	●	●		●	
		90	●				
		100	●	●		●	
		120		●		●	
170	x	8	●				
		10	●				
		12	●				
		15	●	●			
		20	●				
		25	●	●			
		30	●	●			
		35	●				
		40	●				
		50	●	●			
180	x	5	●				
		6	●				
		8	●				
		10	●	●			
		12	●	●			
		15	●	●			
		20	●	●		●	●
		25	●	●		●	●
		30	●	●		●	●

180	x	35	●				
		40	●	●		●	●
		45	●				
		50	●	●		●	●
		60	●	●		●	
		70	●	●			
		80	●	●			
		90		●			
		100	●	●			
190	x	10	●				
		12	●				
		15	●				
		20	●	●			
		25	●				
		30	●				
		40	●				
200	x	5	●				
		6	●				
		8	●				
		10	●	●			
		12	●	●			
		15	●	●			
		20	●	●		●	●
		22	●				
		25	●	●		●	●
		30	●	●	●	●	●
		35	●	●			
		40	●	●		●	●
		50	●	●		●	●
		60	●	●		●	
		70	●	●			
		80	●	●			
		90		●			
		100	●	●			
210	x	10	●				
		15	●				
		20	●				
220	x	8	●				
		10	●				
		12	●				
		15	●				
		20	●	●			
		25	●				
		30	●	●			
		40	●	●			
		50	●				
230	x	10	●				
		15	●				
		20	●				
240	x	8	●				
		10	●				
		12	●				
		15	●				
		20	●				
		25	●				
		30	●	●			

KONTAKT
PRIMO-STAL Sp z o.o.
 ul. Słowackiego 6

59-550 Wojcieszów
 tel. +48 75 75 12 665
 e-mail. biuro@primo-stal.com

240	x	40	●				
250	x	6	●				
		8	●				
		10	●				
		12	●				
		15	●				
		20	●	●		●	
		25	●	●		●	
		30	●	●		●	
		35	●				
		40	●	●		●	
		50	●	●		●	
		60	●	●			
		70	●	●			
		80	●	●			
		90	●	●			
		100	●				
260	x	10	●				
		15	●				
		20	●				
		25	●				
		30	●				
		40	●				
280	x	10	●				
		15	●				
		20	●				
		25	●				
		30	●				
		40	●				
300	x	8	●				
		10	●				
		12	●				
		15	●				
		20	●	●			
		25	●	●			
		30	●	●			
		35	●				
		40	●	●			
		50	●	●			
		60	●	●			
350	x	20	●				
		30	●				
400	x	10	●				
		12	●				
		15	●				
		25	●				

KONTAKT
PRIMO-STAL Sp z o.o.
 ul. Słowackiego 6

59-550 Wojcieszów
 tel. +48 75 75 12 665
 e-mail. biuro@primo-stal.com